Hitmate CWES2 Plugin Pin Replacement Instructions

INTRODUCTION

This document describes the 2nd generation Completely Wireless Epee System (CWES2). If you have the 1st generation CWES, please refer to the CWES User Guide.

PLUGIN PINS

The three Plugin 4mm pins can suffer from damage and wear and therefore they have been designed to be easily replaced. Each CWES comes with 3 spare pins and more are available via our website.

1. Remove the M3 screw from the rear of the pin.

2. Slide the old pin out.

3. Insert the new pin and secure with the M3 screw.